



CULT INTERFACE MOTORCYCLES

BMW R 12 G/S

QUICK ASSEMBLY GUIDE | PANNIER RACK


Tools Required

- ☐ Ratchet + Extension
- ☐ T40 Torx Socket
- ☐ 6mm Allen Socket
- ☐ Blue Loctite (recommended)


Number	QTY	Specifications	Torque (NM)
<u>1</u>	2	M8 x 45mm Allen Head	*
<u>2</u>	2	M8 x 40mm Allen Head	*
<u>3</u>	4	OEM Foot Peg Bolt	*
<u>4</u>	2	Foot Peg Spacer	-
<u>5</u>	2	19mm Spacer	-
<u>6</u>	2	25mm Spacer	-
<u>7</u>	4	M8 Washer	-
<u>8</u>	4	M6 x 20mm Allen Head	10
<u>9</u>	8	M6 Washer	-
<u>10</u>	4	M6 Nyloc Nut	-

* PLEASE REFER TO THE OWNER'S (OR SERVICE) MANUAL FOR **OEM** TORQUE SPECIFICATIONS.*


STEP 1 (Left Side) :



STEP 2 (Right Side - Identical) :



STEP 3:



*** Torque Disclaimer ***

Torque specs provided by Outback Motortek are for guidance only and may reference OEM data. Incorrect torque application from miscalibrated or improperly stored torque wrenches (which can drift by up to 20% within 12 months) may cause broken studs or mounting failures. Always return torque wrenches to 0 ft-lbs when storing, and use blue Loctite (medium strength) on all fasteners to help prevent loosening. Outback Motortek is not responsible for damage or failures caused by mis-torquing or improper installation.